



TMS320DM357

Evaluation Module

*Technical
Reference*

TMS320DM357 Evaluation Module Technical Reference

**511455-0001 Rev. A
December 2008**

**SPECTRUM DIGITAL, INC.
12502 Exchange Drive, Suite 440 Stafford, TX. 77477
Tel: 281.494.4505 Fax: 281.494.5310
sales@spectrumdigital.com www.spectrumdigital.com**

IMPORTANT NOTICE

Spectrum Digital, Inc. reserves the right to make changes to its products or to discontinue any product or service without notice. Customers are advised to obtain the latest version of relevant information to verify that the data being relied on is current before placing orders.

Spectrum Digital, Inc. warrants performance of its products and related software to current specifications in accordance with Spectrum Digital's standard warranty. Testing and other quality control techniques are utilized to the extent deemed necessary to support this warranty.

Please be aware that the products described herein are not intended for use in life-support appliances, devices, or systems. Spectrum Digital does not warrant nor is Spectrum Digital liable for the product described herein to be used in other than a development environment.

Spectrum Digital, Inc. assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein. Nor does Spectrum Digital warrant or represent any license, either express or implied, is granted under any patent right, copyright, or other intellectual property right of Spectrum Digital, Inc. covering or relating to any combination, machine, or process in which such Digital Signal Processing development products or services might be or are used.

WARNING

This equipment is intended for use in a laboratory test environment only. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures necessary to correct this interference.

Contents

1	Introduction to the DM357 Evaluation Module	1-1
<i>Provides you with a description of the DM357 Evaluation Module, key features, and block diagram.</i>		
1.1	Key Features	1-2
1.2	Functional Overview	1-3
1.3	Basic Operation	1-4
1.4	Memory Map	1-5
1.5	Configuration Switch Settings	1-6
1.6	Power Supply	1-7
2	Board Components	2-1
<i>Describes the operation of the major board components on the DM357 Evaluation Module.</i>		
2.1	EMIF Interfaces	2-2
2.1.1	DDR2 Memory Interface	2-2
2.1.2	Flash, NAND Flash, SRAM Memory Interface	2-2
2.1.3	Memory Card Interface	2-2
2.1.4	UART Interface	2-3
2.1.5	EMIF Buffer/Decoder Control CPLD	2-3
2.2	Input Video Port Interfaces	2-4
2.2.1	On Chip Video Output DACs	2-4
2.2.2	AIC33 Interface	2-5
2.2.3	Audio PLL/VCXO Circuit/PLL1705 Clock Generator	2-6
2.3	Ethernet Interface	2-7
2.4	I ² C Interface	2-7
2.4.1	I/O Expanders	2-8
2.4.2	MSP430	2-9
2.5	Daughter Card Interface	2-10
2.6	DM357 Core CPU Clock	2-10
2.7	USB Clock	2-10
2.8	Battery	2-11

3 Physical Specifications	3-1
<i>Describes the physical layout of the DM357 Evaluation Module and its connectors.</i>	
3.1 Board Layout	3-3
3.2 Connectors	3-4
3.2.1 J2, MSP430 JTAG Header	3-5
3.2.2 J3, SD/MMC Connector	3-5
3.2.3 J4, EM_CS2 Routing Connector	3-6
3.2.4 J6, External RESET Interface	3-6
3.2.5 J7, USB Host/Gadget Termination	3-7
3.2.6 J8, Video Out	3-7
3.2.7 J9, USB Capacitance Select	3-8
3.2.8 J10, MiniAB USB Connector	3-9
3.2.9 J11, Composite Video In	3-10
3.2.10 J12, RCA Jack, Video In	3-11
3.2.11 J13, 14 Pin TI JTAG Emulation Header	3-12
3.2.12 J14, +5 Volt Input	3-13
3.2.13 J15, 20 Pin ARM JTAG Emulation Header	3-13
3.2.14 J17, CPLD Programming Header	3-14
3.2.15 J18, MSP430 I/O	3-14
3.2.16 J19, I ² C Bus Expander	3-15
3.2.17 P2, Ethernet Interface	3-15
3.2.18 P3, Stereo Line In	3-16
3.2.19 P4, Headphone Out	3-17
3.2.20 P5, Stereo Line Out	3-17
3.2.21 P6, RS-232 UART	3-18
3.2.22 U3, Infrared Interface	3-19
3.3 Daughter Card Connectors	3-19
3.3.1 DC1, EMIF Expansion Connector	3-20
3.3.2 DC2, GIOV33/Ethernet Connector	3-21
3.3.3 DC3, SPI, McBSP, I ² C Connector	3-22
3.3.4 DC4, Video Input Connector	3-23
3.3.5 DC5, Video Output Connector	3-24
3.3.6 DC6, SD Interface Connector	3-25
3.3.7 DC7, Power Connector	3-25
3.4 LEDs	3-26
3.5 Switches	3-26
3.6.1 S1, EMU0/1 Select Switch	3-27
3.6.2 S3, Processor Configuration/Boot Load Options	3-28
3.6.3 S4, RESET	3-29
3.6.4 S5, User CPLD Option Switch	3-29
3.6.5 SW1, Power On/Off	3-29
3.6 Test Point Connector, JP1	3-30
3.7 Test Points	3-31
A Schematics	A-1
<i>Contains the schematics for the DM357 Evaluation Module</i>	
B Mechanical Information	B-1
<i>Contains the mechanical information about the DM357 Evaluation Module</i>	

About This Manual

This document describes the board level operations of the DM357 Evaluation Module (EVM). The EVM is based on the Texas Instruments DM357 Processor.

The DM357 Evaluation Module is a table top card that allows engineers and software developers to evaluate certain characteristics of the DM357 processor to determine if the processor meets the designers application requirements. Evaluators can create software to execute on board or expand the system in a variety of ways.

Notational Conventions

This document uses the following conventions.

The DM357 Evaluation Module will sometimes be referred to as the DM357 EVM or EVM.

Program listings, program examples, and interactive displays are shown in a special italic typeface. Here is a sample program listing.

equations
!rd = !strobe&rw;

Information About Cautions

This book may contain cautions.

This is an example of a caution statement.

A caution statement describes a situation that could potentially damage your software, or hardware, or other equipment. The information in a caution is provided for your protection. Please read each caution carefully.

Related Documents, Application Notes and User Guides

Information regarding TMS320DM357 technology can be found at the following Texas Instruments website:

<http://www.ti.com>

Table 1: Manual History

Revision	History
A	Alpha Release

Table 2: Board History

PWB Revision	History
A	Alpha Release

Chapter 1

Introduction to the

DM357 EVM

Chapter One provides a description of the DM357 EVM along with the key features and a block diagram of the circuit board.

Topic	Page
1.1 Key Features	1-2
1.2 Functional Overview	1-3
1.3 Basic Operation	1-4
1.4 Memory Map	1-5
1.5 Configuration Switch Settings	1-6
1.6 Power Supply	1-7

1.1 Key Features

The DM357 EVM is a standalone development platform that enables users to evaluate and develop applications for the TI DM357 processor. Schematics, logic equations and application notes are available to ease hardware development and reduce time to market.




Figure 1-1, Block Diagram DM357 EVM

The EVM comes with a full complement of on board devices that suit a wide variety of application environments. Key features include:

- A Texas Instruments DM357 processor with an ARM processor operating up to 270 Mhz. and H.264/MPEG4/JPEG coprocessor
- 1 video input port, supports composite or S video
- 1 video DAC outputs - composite
- 256 Mbytes of DDR2 DRAM
- UART, Media interface (SD card, MMC)
- 64 Mbytes NAND Flash for BOOT, 2 gigabyte NAND storage NAND
- AIC33 stereo codec
- USB2 Interface

- 10/100 MBS Ethernet Interface
- IR Remote Interface, real time clock, via MSP430
- Configurable boot load options
- JTAG emulation interface with 1.8 volt to 3.3 volt translators
- 8 user LEDs
- Single voltage power supply (+5V)
- Expansion connectors for daughter card use

1.2 Functional Overview of the DM357 EVM

The DM357 on the EVM interfaces to on-board peripherals through the 16-bit wide EMIF peripheral interface pins. The DDR2 memory is connected to its own dedicated 32 bit wide bus. The EMIF bus is also connected to the boot NAND, storage NAND, and daughter card expansion connectors which are used for add-in boards.

On board video decoder for composite or s-video and on chip encoders interface video streams to the DM357 processor. One decoder and 1 on chip DAC channel for composite out are standard on the EVM. On screen display functions are implemented in software on the DM357 processor.

An on-board AIC33 codec allows the CPU to transmit and receive analog audio signals. The I²C bus is used for the codec control interface, while the McBSP controls the audio stream. Signal interfacing is done through 3.5mm audio jacks that correspond to microphone input, line input, and line output. The codec can select the line input as the active input.

The EVM includes 8 LEDs, IR interface, and Real time clock which can be used to provide the user with interactive feedback. These interfaces are implemented via software on a MSP430 and are accessed by reading and writing to the I²C registers.

SD/MMC Media card and ethernet MAC interfaces are integrated peripheral on the DM357 processor exploiting its system on a chip architecture.

An included 5V external power supply is used to power the board. On-board switching voltage regulators provide the +1.2V CPU core voltage and +3.3V for peripherals and +1.8V memory and DM357 I/O. The board is held in reset until these supplies are within operating specifications.

Code Composer Studio communicates with the EVM through an external emulator via the 14 TI or 20 pin ARM external JTAG connector.

1.3 Basic Operation

The EVM is designed to work with TI's Code Composer Studio IDETM, or standard GDB tool environments. Code Composer communicates with the board through an external JTAG emulator.


Detailed information about the EVM including examples and reference material is available on the EVM's CD-ROM.

1.4 Memory Map

The DM357 processor has a large byte addressable address space. However, some limitations to byte addressing may be present depending on the board to device peripheral interconnection. Program code and data can be placed anywhere in the unified address space. Addresses are multiple sizes depending on hardware implementation. Refer to the appropriate device data sheets for more details.

The memory map shows the address space of a DM357 processor on the left with specific details of how each region is used on the right.

The part incorporates a dual EMIF interface. One dedicated EMIF directly interfaces to the DDR2 memory. The other EMIF has 4 separate addressable regions called chip enable spaces (CE2-CE5). The boot NAND Flash, or daughter card are mapped into CE2 space and selectable via J4. Daughter cards use CE2 and CE3. When CE2 is used for daughter card interfacing J4 must be set appropriately. CE4 is used to interface to storage NAND.



1.5 Configuration Switch Settings

The EVM has a single 10 position configuration switch that allow users to control the operational state of the processor when it is released from reset. The configuration switch is labeled S3 on the EVM board.

Switch S3 configures the boot mode that will be used when the processor starts executing. By default the switches are configured to EMIF boot (out of 8-bit NAND Flash) in little endian mode. The settings for switch S3 in chapter 3.

1.6 Power Supply

The EVM operates from a single +5V external power supply connected to the main power input (J14), a 2.5 MM. barrel-type plug. Internally, the +5V input is converted into +1.2V, +1.8V and +3.3V using Texas Instruments swift voltage regulators. The +1.2V supply is used for the CPU core while the +3.3V supply is used for the CPU's I/O buffers and other chips on the board. The +1.8 volt supply is used for DM357 I/O, low voltage memory, and peripherals, and DDR2 memory.

There are four power test points on the EVM; TP14, TP25, TP26, and TP43. These test points provide a convenient mechanism to check the EVM's multiple power supplies. The table below shows the voltages for each test point and what the supply is used for.

Table 1: Power Test Points

Test Point	Voltage	Voltage Use
TP43	+1.2 V	DM357 Core
TP25	+1.2 V	DM357 Core/Power Down
TP26	+1.8 V	DDR2 Memory, CPU I/O, and logic
TP14	+3.3V	CPU I/O and logic

Chapter 2

Board Components

This chapter describes the operation of the major board components on the DM357 EVM.

Topic	Page
2.1 EMIF Interfaces	2-2
2.1.1 DDR2 Memory Interface	2-2
2.1.2 NAND Flash Interface	2-2
2.1.3 Storage NAND Interface	2-2
2.1.4 Memory Card Interface	2-2
2.1.5 UART Interface	2-3
2.1.6 EMIF Buffer/Decoder Control CPLD	2-3
2.2 Input Video Port Interfaces	2-4
2.2.1 On Chip Video Output DACs	2-4
2.2.2 AIC33 Interface	2-5
2.2.3 Audio PLL/VCXO Circuit/PLL1705 Clock Generator	2-6
2.3 Ethernet Interface	2-7
2.4 I²C Interface	2-7
2.4.1 I/O Expanders	2-8
2.4.2 MSP430	2-9
2.5 Daughter Card Interface	2-10
2.6 DM357 Core CPU Clock	2-10
2.7 USB Clock	2-10
2.8 Battery	2-11

2.1 EMIF Interfaces

A separate 16 bit EMIF with four chip enables divide up the address space and allow for asynchronous accesses on the EVM. The EVM has a dedicated chip enables. CE2 is used for the boot NAND Flash. Both CE2 and/or CE3 can be routed to the daughter card interface connectors. CE4 is used for storage NAND flash.

Table 1: EMIF Interfaces

Chip Select	Function
CE2	Boot NAND Flash (see JP4 definition)
CE2	Daughter Card Interface (see JP4 definition)
CE3	Daughter Card Interface
CE4	Storage NAND Flash
CE5	Reserved

2.1.1 DDR2 Memory Interface

The DM357 device incorporates a dedicated 32 bit wide DDR2 memory bus. The EVM uses two gigabit 16 bit wide memories on this bus, for a total of 256 megabytes of memory for program, data, and video storage. The internal DDR controller uses a PLL to control the DDR memory timing. The interface supports rates up to 166 Mhz., and is clocked on differential edges for optimal performance. Memory refresh for DDR2 is handled automatically by the DM357 internal DDR controller.

2.1.2 Boot NAND Flash Interface

The DM357 has 64 megabytes of Boot NAND Flash mapped into the CE2 space. This NAND Flash memory is used for boot loading. The CE2 space is configured as 8 bit wide for NAND flash usage.

2.1.3 Storage NAND Interface

The EVM interfaces to 2 gigabytes of storage NAND flash mapped to CE4 space. CE4 is configured to 8 bit wide access for storage NAND. The CPLD incorporates 1.8 to 3.3 volt level translators to interface to the NAND.

2.1.4 Memory Card Interface

The EVM supports MMC/SD media cards via the on chip controller.


2.1.5 UART Interface

The internal UART0 on the DM357 device is driven to connector J6. The UART's interface is level shifted and routed to the RS-232 line drivers prior to being brought out to a DB-9 connector, J6.

2.1.6 EMIF Buffer/Decoder Control CPLD

The EMIF buffer and decode functions are implemented with a CPLD. The EVM board incorporates an Altera MAX II EPM240TCG100 device. The device has 2 banks of I/O. One bank is used for +1.8 volt signals. The other bank is for +3.3 volt signals. This allows the device to do level shifting.

The CPLD incorporates the storage NAND level translators and decode interface along with a divide by 8 counter for video synchronization. The CPLD also incorporates various glue logic for the EVM.



2.2 Input Video Port Interfaces

The DM357 EVM supports video capture via the devices internal video ports. A Texas Instruments TVP5146 is used to decode composite video or S-video inputs into the device after being level shifted. J11 is used for the S-video inputs and J12 for the composite inputs on the EVM.

User inputs can be driven via daughter card connector DC4 when the on board level translator is tristate via driving control Capture Enable signal high on DC4.

2.2.1 On Chip Video Output DACs

The DM357 incorporates 1 output DAC to interface to composite video. The DAC is buffered via opamps and driven to connector, J8.


2.2.2 AIC33 Interface

The EVM uses a Texas Instruments TLV320AIC33 stereo codec for input and output of audio signals. The codec samples analog signals on the microphone or line inputs and converts them into digital data so it can be processed by the CPU. When the processor is finished with the data it uses the codec to convert the samples back into analog signals on the line output so the user can hear the output.

The codec communicates using two serial channels, one to control the codec's internal configuration registers and one to send and receive digital audio samples. The I²C bus is used as the unidirectional control channel. The control channel is generally only used when configuring the codec, it is typically idle when audio data is being transmitted,

The McBSP is used as the bi-directional data channel. All audio data flows through the data channel. Many data formats are supported based on the three variables of sample width, clock signal source and serial data format. The EVM examples generally use a 16-bit sample width with the codec in master mode so it generates the frame sync and bit clocks at the correct sample rate without effort on the processor side.

The codec has a programmable clock from a PLL1705 PLL device. The internal sample rate generator subdivides the default system clock to generate common audio frequencies. The sample rate is set by a codec register. The figure below shows the codec interface on the DM357 EVM.



2.2.3 Audio PLL/VCXO Circuit/PLL1705 Clock Generator

The DM357 EVM implements a multiple PLL clock generator for creating the Audio clocks for the board.


In streaming video applications the audio and video sequences can lose synchronization. The DM357 uses a VCXO interpolation circuit to incrementally speed up or slow down the STCLK input to allow for this synchronization to remain locked.

The PWM0 and timer inputs on DM357 are used to control this feature. The PWM0 pin drives a PICX100-27W Voltage Controlled Oscillator which is divided by 8 in the CPLD and fed back into the timer input pin.

The STCLK is also a source clock for the PLL1705 programmable PLL device. This device creates the clocks for the AIC33 Codec, daughter card VIDCLK an AUDIOCLK.

The PLL1705 is programmable via an I²C and Expander U18. Software sequencing on the I/O expander is required to interface correctly to the PLL1708's programmable inputs.

The diagram below is a simplified diagram of this clocking scheme.



2.3 Ethernet Interface


The DM357 integrates an ethernet MAC on chip. This interface is routed to the PHY via CBT switches. The EVM uses an Intel LXT971 PHY. The 10/100 Mbit interface is isolated and brought out to a RJ-45 standard ethernet connector, P2. The PHY directly interfaces to the DM357. The ethernet address is stored in the I²C serial ROM during manufacturing.

The RJ-45 has 2 LEDs integrated into its connector. The LEDs are green and yellow and indicate the status of the ethernet link. The green LED, when on, indicates link and when blinking indicates link activity. The yellow LED, when illuminated, indicates full duplex mode.

When configuring the PHY use the high drive option in the PHY register 26 to compensate for the routing length and extra capacitance of the CBT switches.

2.4 I²C Interface

The I²C bus on the DM357 is ideal for interfacing to the control registers of many devices. On the DM357 EVM the I²C bus is used to configure the video decoder, stereo Codec, I/O expanders, and communicate with the MSP430. An I²C ROM is also interfaced via the serial bus. The format of the bus is shown in the figure below.



The addresses of the on board peripherals are shown in the table below.

Table 2: I²C Memory Map

Device	Address	R/W	Function
TVP5146	0x5D	R/W	Capture 1 Decoder
PCF 8574A	0x38	R/W	LEDs
PCF 8574A	0x39	R/W	PLL/User Switch
PCF 8574A	0x3A	R/W	Peripheral Selects
TLV320AIC33	0x1B	R/W	CODEC
24WC256	0x50	R/W	I ² C EEPROM
MSP430	0x23	R/W	LEDs, IR, RTC

2.4.1 I/O Expanders

The DM357 EVM uses three I²C expanders to handle various bit I/O functions. Each of these is an 8 bit I/O expander, a PCF8574A. At Power Up Reset the expanders are initialized to 0xFF, all ones. The functions for each of the I/O expanders are shown in the tables below.

Table 3: U2, I/O Expander

Pin Number	Function	States
P0	User LED DS8	0 = Turns LED On, 1 = Turns LED Off
P1	User LED DS7	0 = Turns LED On, 1 = Turns LED Off
P2	User LED DS6	0 = Turns LED On, 1 = Turns LED Off
P3	User LED DS5	0 = Turns LED On, 1 = Turns LED Off
P4	User LED DS4	0 = Turns LED On, 1 = Turns LED Off
P5	User LED DS3	0 = Turns LED On, 1 = Turns LED Off
P6	User LED DS2	0 = Turns LED On, 1 = Turns LED Off
P7	User LED DS1	0 = Turns LED On, 1 = Turns LED Off

Table 4: U18, I/O Expander

Pin Number	Function
P0	PLL Program Interface, PLL CSEL Pin
P1	PLL Program Interface, PLL SR Pin
P2	PLL Program Interface, PLL FS1 Pin
P3	PLL Program Interface, PLL FS2 Pin
P4	Spare IO1
P5	Spare IO2
P6	Spare IO3
P7	User DIP Switch *

* - useful as input only
High Input - Switch in "ON" Position
Low Input - Switch in "OFF" Position

Table 5: U35, I/O Expander

Pin Number	Function	State
P0	Reserved	
P1	VDD IMX Enable	0 = Disables VDDIMX supply
P2	Reserved	
P3	Reserved	
P4	Reserved	
P5	Reserved	
P6	Reserved	
P7	Reserved	

2.4.2 MSP430

The DM357 EVM incorporates infrared remote, real time clock, and some bit I/O in a MSP430 microcontroller. The I²C interface is used on the DM357 processor to communicate to the MSP430. The MSP430 acts as a slave device on the I²C bus.

2.5 Daughter Card Interfaces

The EVM provides expansion connectors that can be used to accept plug-in daughter cards. The daughter card allows users to build on their EVM platform to extend its capabilities and provide customer and application specific I/O. The expansion connectors are for all major interfaces including memory, peripherals, and video expansion.

Spectrum Digital produces the THS8200 daughter card (part # 7xxxxx) which plugs onto the connector.

The pin outs for this interface are documented in Section 3.

The memory connector provides access to the CPU's EMIF signals to interface with memories and memory mapped devices.

The video capture port is brought out to the daughter card interface. Four signals are used to disable the on board video peripherals so that they can be used by the expansion connector. The table below indicates the operation of these signals.

Table 6: Daughter Card Video Enable

Signal	State To Enable Daughter Card Use	DM357 Signals Enables
CAPTURE_EN	1	DC4 YI0-YI7 PCLK,VD,HD
McBSP_EN	1	DC3 McBSP
ENET_ENABLE	1	DC2 GIOV33 pins

Other than the buffering, most daughter card signals are not modified on the board.

2.6 DM357 Core CPU Clock

The DM357 EVM uses a 27 Megahertz crystal to generate the input clock. The DM357 has an internal PLL which can multiply the input clock to generate the internal clock. The PLL multiplier is set via software on the DM357 device.

2.7 USB Clock

The DM357 EVM uses a 24 Mhz crystal for the USB II clock generator. The USB controller is completely integrated in the DM357 device.

2.8 Battery

The DM357 EVM incorporates a battery holder to provide backup power to the MSP430's real time clock when the power is not applied to the board. The optional battery should be +3 volt 20 millimeter coin type Lithium single cell.

Some common part numbers for batteries which should operate in the EVM are shown in the table below.

Table 7: Battery Part Numbers

Part Numbers
CR2032
DL2032
BR2032
CR2025
BR2025
CR2016
BR2016
DL2016

These batteries are available from Duracell, Eveready, Panasonic, Ray-O-Vac, Sanyo, Sony, Sieko, Toshiba, Varta, and other battery manufacturers.

Chapter 3

Physical Description


This chapter describes the physical layout of the DM357 EVM and its interfaces.

Topic	Page
3.1 Board Layout	3-3
3.2 Connectors	3-4
3.2.1 J2, MSP430 JTAG Header	3-5
3.2.2 J3, SD/MMC Connector	3-5
3.2.3 J4, EM_CS2 Routing Connector	3-6
3.2.4 J6, External RESET Interface	3-6
3.2.5 J7, USB Host/Gadget Termination	3-7
3.2.6 J8, Video Out	3-7
3.2.7 J9, USB Capacitance Select	3-8
3.2.8 J10, MiniAB USB Connector	3-9
3.2.9 J11, Composite Video In	3-10
3.2.10 J12, RCA Jack, Video In	3-11
3.2.11 J13, 14 Pin TI JTAG Emulation Header	3-12
3.2.12 J14, +5 Volt Input	3-13
3.2.13 J15, 20 Pin ARM JTAG Emulation Header	3-13
3.2.14 J17, CPLD Programming Header	3-14
3.2.15 J18, MSP430 I/O	3-14
3.2.16 J19, I ² C Bus Expander	3-15
3.2.17 P2, Ethernet Interface	3-15
3.2.18 P3, Stereo Line In	3-16
3.2.19 P4, Headphone Out	3-17
3.2.20 P5, Stereo Line Out	3-17
3.2.21 P6, RS-232 UART	3-18
3.2.22 U3, Infrared Interface	3-19

Topic	Page
3.3 Daughter Card Connectors	3-19
3.3.1 DC1, EMIF Expansion Connector	3-20
3.3.2 DC2, EMAC/GIO Connector	3-21
3.3.3 DC3, McBSP/SPI Expansion	3-22
3.3.4 DC4, Video Input expansion	3-23
3.3.5 DC5, Video Output Expansion	3-24
3.3.6 DC6, SD Interface Expansion	3-25
3.3.7 DC7, Power Expansion	3-25
3.4 LEDs	3-26
3.5 Switches	3-26
3.5.1 S1, EMU0/1 Select Switch	3-27
3.5.2 S3, Processor Configuration/Boot Load Options	3-28
3.5.3 S4, RESET	3-29
3.5.4 S5, User CPLD Option Switch	3-29
3.5.5 SW1, Power On/Off	3-29
3.6 Test Point Connector, JP1	3-30
3.7 Test Points	3-31

3.1 Board Layout

The DM357 EVM is a 6.75 x 10.0 inch (171 x 254 mm.) ten (10) layer printed circuit board which is powered by an external +5 volt only power supply. Figure 3-1 shows the layout of the DM357 EVM.



3.2 Connectors

The EVM has twenty-nine (29) connectors or interfaces to various peripherals. These connectors are described in the following sections.

Table 1: Connectors

Connector	Size	Function
J2	2 x 7	MSP430 JTAG
J3	24	SD/MMC
J4	2 x 2	EM_CS2 Routing
J6	2	External RESET Input
J7	2	USB Host/Client Termination
J8	RCA	Video Out
J9	1 x 3	USB Capacitance Select
J10	4	MiniAB USB
J11	4 Pin DIN	Composite Video In
J12	RCA	Video In
J13	2 x 7	14 Pin TI Emulation Header
J14	2.5 mm	+5 Volt Input
J15	2 x 10	20 Pin ARM Emulation Header
J17	5 x 2	CPLD Programming Header (Factory Use)
J18	1 x 8, 2mm	MSP430 I/O
J19	1 x 8, 2mm	I/O Header
P2	RJ-45	Ethernet
P3	Dual RCA	Stereo Line In
P4	3.5 mm	Headphone Out
P5	Dual RCA	Stereo Line Out
P6	9	RS-232 UART
DC1	2 x 35	EMIF Expansion
DC2	2 x 20	EMAC/GIO Expansion
DC3	2 x 15	McBSP/SPI Expansion
DC4	2 x 25	Video Input Expansion
DC5	2 x 25	Video Output Expansion
DC6	2 x 5	SD Expansion
DC7	2 x 5	Voltage Expansion
U3		IR Interface

3.2.1 J2, MSP430 JTAG Header

The J2, MSP430 JTAG header, is used to provide a programming interface to the MSP430 microcontroller. The pinout for the J2 connector is shown in the table below.

Table 2: J2, MSP430 JTAG Header

Pin #	Signal	Pin #	Signal
1	430_TDO	2	NC
3	430_TDI	4	MSP430_3V3
5	430_TMS	6	NC
7	430_TCK	8	430_TEST/VPP
9	GND	10	NC
11	NC	12	NC
13	NC	14	NC

3.2.2 J3, SD/MMC Connector

The J3 SD/MMC connector is used to provide an interface to a SD/MMC card. The pinout for the J3 connector is shown in the table below.

Table 3: J3, SD/MMC Connector

Pin #	Signal	Pin #	Signal
1	SD_DATA3	2	SD_CMD
3	GND	4	VCC_3.3V
5	SD_CLK	6	GND
7	SD_DATA0	8	SD_DATA1
9	SD_DATA2	10	GND


3.2.3 J4, EM_CS2 Routing Connector

The J4 connector is actually a 4 position jumper that is used to select the type of memory that the EM_CS2 signal is routed to. The EM_CS2 can be routed to either of the two signals shown in the figure below. Only one (1) device can be selected at a time. To reconfigure this signal, power down the EVM, change the jumper, and then power the board back up. Do **NOT** change this jumper with the power on. The pin outs are shown in the table below.

Table 4: J4, EM_CS2 Routing Connector


Pin #	Signal	Pin #	Signal
1	EM_CS2	3	NAND_CEz
2	EM_CS2	4	DC_EM_CS2

The figure below shows the two possible selections.




3.2.4 J6, External RESET Interface

The J6 connector is a 2 position jumper is used to externally reset the board. This connector is unpopulated as shipped from the factory. This circuitry parallels the RESET switch, S4. The figure below represents this connector.




3.2.5 J7, USB Host/Gadget Termination

The J7 connector is a 3 position jumper that is used to select the termination for the USB host/gadget configuration on USB connector J10. Either the +3.3V (1-2 position) for USB Gadget or Ground (2-3 position) for Host must be selected to properly enable the mode of operation on the DM357 USB controller. To reconfigure this termination, power down the EVM, change the jumper, and then power the board back up. Do **NOT** change this jumper with the power on. The figure below shows the signals on this connector.



3.2.6 J8, Video Out

The J8 connector is an RCA jack providing 1 DAC output. Do **NOT** plug into these connectors with the power on. This connector is driven by the signal DAC_IOUTA through the op-amp U50. The figure below shows this connector as viewed from the card edge.



3.2.7 J9, USB Capacitance Select

The J9 jumper is a 3 position jumper header of which only pins 1 and 2 are used. This jumper is used to provide more capacitance when the USB connector is used in the host mode. When the jumper is shorted the extra capacitance is provided. These open and shorted position are shown below.




Table 5: J9, USB Capacitance Select

Position	Function
Open	6.8 uF Capacitance
Shorted	106.8 uF Capacitance

3.2.8 J10, MiniAB USB Connector

Connector J10 is a mini A/B USB connector. The pinout for the J10 connector is shown in the table below.

Table 6: J10, MiniAB USB Connector

Pins	Signal
1	USB_VBUS_CONN
2	USB_DM
3	USB_DP
4	USB_ID
5-9	USB_SHIELD/GND

The EVM incorporates the ability to toggle the ID pin on the USB connector via software control. The USB_ID pin on the DM357 controls this function.

For “USB ON The Go” mode remove header J7. This will allow the cable to configure the ID pin on the DM357 processor.

The EVM supplies up to 500 mA of current to the USB_VBUS via a TPS2065D DC/DC converter. This is enabled via the DM357’s DRV_VBUS pin. J9 supplies extra capacitance for host mode operations.

3.2.9 J11, Composite Video In

Connector J11 is a four pin mini-din connector which interfaces to the TVP5146 encoder. This connector brings in a video signal (LUMA) to pin 9 on the TVP5146. Do **NOT** plug into this connector with the power on. The figure below shows this connector as viewed from the card edge.




Table 7: J11, Video In, Mini-Din Connector

Pin #	Signal Name
1	GND
2	GND
3	LUMA
4	Chroma

3.2.10 J12, RCA Jack, Video In

J13 is an RCA jack used as the CVBS/Y input to the TVP5146. The figure below shows this connector as viewed from the card edge.




Figure 3-8, J12, Video In RCA Jack

Table 8: J12, Video In RCA Jack

Pin #	Signal Name
1	DEC_GND
2	VI_2_B, U51, Pin 8, TVP5146
3	DEC_GND
2	DEC_GND

3.2.11 J13, 14 Pin TI JTAG Emulation Header

Connector J13 is a 2 x 7 double row male header with pin 6 clipped to serve as a key. This is the standard interface used by JTAG emulators to interface to Texas Instruments processors. The pinout for the connector is shown in the figure below.

TMS	1	2	TRST-	
TDI	3	4	GND	Header Dimensions
PD (+3.3V)	5	6	no pin (key)	Pin-to-Pin spacing, 0.100 in. (X,Y)
TDO	7	8	GND	Pin width, 0.025-in. square post
TCK-RET	9	10	GND	Pin length, 0.235-in. nominal
TCK	11	12	GND	
EMU0	13	14	EMU1	

Figure 3-9, J13, 14 Pin External JTAG Connector

The signal names for each pin are shown in the table below.


Table 9: J13, 14 Pin External JTAG Connector

Pin #	Signal Name	Pin #	Signal Name
1	TI TMS	2	TI TRSTn
3	TI TDI	4	GND
5	TI PWR DECT	6	no pin - key
7	TI TDO	8	GND
9	TI TCK RET	10	GND
11	TI TCK	12	GND
13	TI EMU0	14	TI EMU1

* **Note:** EMU0/EMU1 mode must be selected to ICEPICK mode

3.2.12 J14, +5 Volt Input

Connector J14 is the input power connector. This connector brings in +5 volts to the EVM. This is a 2.5mm. jack. Inside of the jack is tied to On/Off power switch SW1. The other side is tied to ground and LED DS9. The figure below shows this connector as viewed from the card edge.




3.2.13 J15, 20 Pin ARM JTAG Emulation Header

The J15 emulation header is used to provide an interface to generic ARM9 JTAG emulators. The pinout for this connector is shown in the table below.

Table 10: J15, 20 Pin ARM JTAG Emulation Header

Pin #	Signal	Pin #	Signal
1	VCC_3V3	2	VCC_3V3
3	ARM_TRSTn	4	Ground
5	ARM_TDI	6	Ground
7	ARM_TMS	8	Ground
9	ARM_TCK	10	Ground
11	ARM_TCKRET	12	Ground
13	ARM_TDO	14	Ground
15	ARM_RSTn	16	Ground
17	NC	18	Ground
19	NC	20	Ground

Note: EMU0/EMU1 switch, S1, must be set to ARM mode. This is shown in the figure below. See section 3.5.1 for more details.



3.2.14 J17, CPLD Programming Header

Connector J17 is a 10 pin header that provides a programming interface to the FPGA, U14. Do **NOT** plug into this connector with the power on. The table below shows the signals on this connector. This connector is for factory use only. Reprogramming this CPLD affects the functionality of your EVM.

Table 11: J17, CPLD Programming Header

Pin #	Signal	Pin #	Signal
1	ISR_TCK	2	GND
3	ISR_TDO	4	VCC_1.8V
5	ISR_TMS	6	NC
7	NC	8	NC
9	ISR_TDI	10	GND

3.2.15 J18, MSP430 I/O

Connector J18 brings out the I/O lines from the MSP430. These lines are pulled up to +3.3 volts through RN22. The signals on this connector are shown in the table below.

Table 12: J18, MSP430 I/O

Pin #	Signal
1	P2.2/CAOUT/TAO
2	P2.3/CA0/TA1
3	P2.4/CA1/TA2
4	P3.0/STE0/A5
5	P3.1/SIMO0
6	P3.2/SOMI0
7	P3.3/UCLK0
8	P3.7/A7

3.2.16 J19, I²C Bus Expander

Connector J19 brings out the lines from U35, PCF8574A, the remote 8 bit expander for the I²C bus. The signals on this connector are shown in the table below.

Table 13: J18, I²C Bus Expander

Pin #	Signal
1	PIO 0, U35, Pin 4
2	VDDIMX EN, U35, Pin 5
3	PIO 2, U35, Pin 6
4	PIO 3, U35, Pin 7
5	PIO 4, U35, Pin 9
6	PIO 5, U35, Pin 10
7	PIO 6, U35, Pin 11
8	PIO 7, U35, Pin 12

3.2.17 P2, Ethernet

The P2 connector is used to provide an Ethernet interface. P2 integrates the magnetics and standard RJ-45 connector. The two tables below show the signals present on the magnetics interface and the connector side.

Table 14: P2, Magnetics/LEDs Interface Signals

Pin #	Signal	Pin #	Signal
1	TX+, U58, Pin 19	2	TX-, U58, Pin 20
3	RX+, U58, Pin 23	4	TXD-CT, U58, Pin 22
5	RXD-CT, NC	6	RXD-, U58, Pin 24
7	NC1	8	GND
9	LED1+	10	LED1-
11	LED2+	12	LED2-

3.2.18 P3, Dual Stereo Line In

The P3 connector provides a stereo input (lower) and microphone input (upper) to the TBL320AIC331 on the EVM. A view of the connector from the card edge is shown in the figure below. The signals present on this connector are defined in the following table.




Table 15: P3, Dual Stereo Line In

Pin #	Signal	Input
1	Isolated Ground	Mic
2	MIC3L/MIC3R, U52, Pins A1,B3	Mic
3	MIC3L/MIC3R, U52, Pins A1,B3	Mic
4	Isolated Ground	Line In
5	LINE1R+/LINE2R+, U52, Pins B4,B7	Line In
6	LINE1L+/LINE2L+, U52, Pins A4,A6	Line In

3.2.19 P4, Headphone Out

The P4 connector is a 3.5 mm. stereo headphone output from the TVL320AIC331ZQE, U52, on the EVM. A view of the connector from the card edge is shown in the figure below.




Figure 3-13, P6, Headphone Out Interface

The signals present on this connector are defined in the following table.

Table 16: P4, Headphone Out Interface

Pin #	AIC331 Signal
1	GND
2	HPOUT, U52, Pin D1
3	HPROUT, U52, Pin G1
4	NC

3.2.20 P5, Stereo Line Out

The P5 connector is a dual output RCA jack bringing audio from the TVL320AIC331 on the EVM. A view of the connector from the card edge is shown in the figure below. The signals present on this connector are defined in the following table.




Figure 3-14, P5, Stereo Line Out

Table 17: P5, Stereo Line Out

Pin #	Signal
1	Isolated Ground
2	LEFT_LO+, U52, Pin J4
3	RIGHT_LO+, U52, Pin J6

3.2.21 P6, RS-232 UART

The P6 connector is a 9 pin male D-connector which provides a UART interface to the EVM. This connector interfaces to the MAX 3221 RS-232 line driver (U64) and is located on the top side of the board. A view of the connector from the card edge is shown in the figure below. The signals present on this connector are defined in the following table.




Figure 3-15, P6, DB9 Male Connector

The pin numbers and their corresponding signals are shown in the table below. This corresponds to a standard dual row to DB-9 connector interface used on personal computers.

Table 18: P6, UART Pinout

Pin #	Signal Name	Direction
1	NC	N/A
2	S_A_RXD	In
3	S_A_TXD	Out
4	NC	N/A
5	GND	N/A
6	NC	N/A
7	Connected to pin 8	Out
8	Connected to pin 7	Out
9	NC	N/A
10,11	Earth Ground	N/A

3.2.22 U3, Infrared Interface

U3 is an infrared receiver mounted on the edge of the board. This device interfaces to the MSP430 microcontroller. The view of U3 is shown from a board edge view in the figure below.




Figure 3-16, U3, IR Interface, Card Edge View

The receiver supports interaction with an Infrared remote control included with your EVM.

Table 19: U3, Infrared Interface

U3 Pin #	MSP430 Signal, Pin #
1	P1.2/TA1, U4, Pin 23
2	GND
3	VCC_3V3

3.3 Daughter Card Connectors

The EVM has seven connectors that are available for daughter card connections. These connectors make many of the signals on the EVM available to be used by external logic. The signals on each of the connectors are described in the following tables. The table below lists the connectors.

Table 20: Daughter Card Connectors

Connector	Size	Function	Schematic Page
DC1	2x35	EMIF	29
DC2	2x20	GIOV33/Ethernet	31
DC3	2x15	SPI, McBSP, I ² C	31
DC4	2x20	Video In	30
DC5	2x25	Video Out	30
DC6	2x5	SD Interface	31
DC7	2x5	Power	35

3.3.1 DC1, EMIF Expansion Connector

Table 21: DC1, EMIF Expansion Connector

Pin #	Signal	Pin #	Signal
1	EM_A21	2	EM_A20
3	EM_A19	4	EM_A18
5	EM_A17	6	EM_A16
7	EM_A15	8	EM_A14
9	GND	10	GND
11	EM_A13	12	EM_A12
13	EM_A11	14	EM_A10
15	EM_A9	16	EM_A8
17	EM_A7	18	EM_A6
19	GND	20	GND
21	EM_A5	22	EM_A4
23	EM_A3	24	CLE_EM_A2
25	ALE_EM_A1	26	EM_A0
27	GND	28	GND
29	GPIO51	30	GPIO52
31	EM_BA1	32	EM_BA0
33	WRITE_WE	34	READ_OE
35	WAIT/BUSY	36	EM_RNW
37	GND	38	GND
39	EM_D15	40	EM_D14
41	EM_D13	42	EM_D12
43	EM_D11	44	EM_D10
45	GND	46	GND
47	EM_D9	48	EM_D8
49	EM_D7	50	EM_D6
51	EM_D5	52	EM_D4
53	GND	54	GND
55	EM_D3	56	EM_D2
57	EM_D1	58	EM_D0
59	EM_CS3	60	DC_EM_CS2
61	1.8V.SYS_RESETz	62	CLKOUT0
63	GND	64	GND
65	VCC_3.3V	66	VCC_3.3V
67	GND	68	GND
69	VCC_5V	70	VCC_1.8V

3.3.2 DC2, EMAC/GIO Connector

Table 22: DC2, EMAC/GIO Connector

Pin #	Signal	Pin #	Signal
1	GND	2	GND
3	GIOV33_0	4	GIOV33_1
5	GIOV33_2	6	GIOV33_3
7	GIOV33_4	8	GIOV33_5
9	GND	10	GND
11	GIOV33_6	12	GIOV33_7
13	GIOV33_8	14	GIOV33_9
15	GIOV33_10	16	GIOV33_11
17	GND	18	GND
19	GIOV33_12	20	GIOV33_13
21	GIOV33_14	22	GIOV33_15
23	GIOV33_16	24	GND
25	GND	26	3V3.SYS_RESETz
27	ENET_ENABLEz	28	GND
29	VCC_1.8V	30	3V3.UART_RXD1
31	VCC_1.8V	32	3V3.UART_TXD1
33	GND	34	GND
35	VCC_3.3V	36	VCC_3.3V
37	VCC_5V	38	VCC_5V
39	GND	40	GND

3.3.3 DC3, McBSP/SPI Expansion

Table 23: DC3, McBSP/SPI Expansion

Pin #	Signal	Pin #	Signal
1	SPI_EN1	2	SPI_EN0
3	SPI_DI	4	SPI_DO
5	SPI_CLK	6	TIMER_IN_DC3
7	GND	8	GND
9	DR	10	DX
11	CLKR	12	CLKX
13	FSR	14	FSX
15	GND	16	GND
17	1.8V.SYS_RESETz	18	1.8V.I2C_CLK
19	McBSP_EN	20	1.8V.I2C_DATA
21	AUDIO_CLK	22	GND
23	GND	24	1.8V_DC3_PCLK
25	VCC_3.3V	26	VCC_3.3V
27	GND	28	GND
29	VCC_5V	30	VCC_1.8V

3.3.4 DC4, Video Input Expansion

Table 24: DC4, Video Input Expansion

Pin #	Signal	Pin #	Signal
1	1.8V.SYS_RESETz	2	CAPTURE_EN
3	GND	4	GND
5	GIO1	6	GIO4
7	GND	8	GND
9	PWM1	10	PWM2
11	GND	12	GND
13	Y10	14	Y11
15	Y12	16	Y13
17	Y14	18	Y15
19	Y16	20	Y15
21	GND	22	GND
23	GND	24	HD
25	PCLK/1V8.DC_PCLK	26	VD
27	GND	28	GND
29	CI0	30	CI1
31	CI2	32	CI3
33	CI4	34	CI5
35	CI6	36	CI7
37	GND	38	GND
39	1V8.I2C_CLK	40	1V8.I2C_DATA
41	VCC_1.8V	42	VCC_1.8V
43	GND	44	GND
45	VCC_3.3V	46	VCC_3.3V
47	GND	48	GND
49	VCC_5V	50	VCC_5V

3.3.5 DC5, Video Output Expansion

Table 25: DC5, Video Output Expansion

Pin #	Signal	Pin #	Signal
1	GIO0	2	GIO2
3	GIO3	4	GIO5
5	GIO6	6	GIO38
7	GND	8	GND
9	COUT0	10	COUT1
11	COUT2	12	COUT3
13	COUT4	14	COUT5
15	COUT6	16	COUT7
17	GND	18	GND
19	VPBECLK/VID_CLK	20	H SYNC
21	GND	22	GND
23	VCLK	24	V SYNC
25	GND	26	GND
27	YOUT0	28	YOUT1
29	YOUT2	30	YOUT3
31	YOUT4	32	YOUT5
33	YOUT6	34	YOUT7
35	GND	36	GND
37	1.8V.I2C_CLK	38	1.8V.SYS_RESETz
39	1.8V.I2C_DATA	40	GND
41	VCC_1.8V	42	VCC_1.8V
43	GND	44	GND
45	VCC_3.3V	46	VCC_3.3V
47	GND	48	GND
49	VCC_5V	50	VCC_5V

3.3.6 DC6, SD Interface Expansion

Table 26: DC6, SD Interface Expansion

Pin #	Signal	Pin #	Signal
1	SD_CLK	2	SD_CMD
3	GND	4	GND
5	SD_DATA0	6	SD_DATA1
7	SD_DATA2	8	SD_DATA3
9	GND	10	GND

3.3.7 DC7, Power Expansion

Table 27: DC7, Power Expansion

Pin #	Signal	Pin #	Signal
1	VDDIMX_EN	2	GND
3	CORE_SUPPLY	4	CORE_SUPPLY
5	GND	6	GND
7	VCC_1.8V	8	VCC_1.8V
9	GND	10	GND

3.4 LEDs

The EVM has ten (10) LEDs which are located on the top side of the board. Eight of these LEDs (DS1-8) are under user control and addressed over the I²C bus. One LED (DS9) indicates the presence of +5 volts on the board. The remaining LED (DS10) is tied to the CPLD, U14, B2.PIN86, and +3.3 volts. Additional information regarding the LEDs are shown in the table below.

Table 28: LEDs

LED #	Use	Color	Schematic Page
DS1	User Defined	Green	23
DS2	User Defined	Green	23
DS3	User Defined	Green	23
DS4	User Defined	Green	23
DS5	User Defined	Green	23
DS6	User Defined	Green	23
DS7	User Defined	Green	23
DS8	User Defined	Green	23
DS9	+5V	Green	29
DS10	+3.3V, U14, B2.PIN86	Red	14

3.5 Switches

The EVM has five (5) switches. The function of these switches are shown in the table below.

Table 29: Switches

Switch	Function	Type	Schematic Page
S1	EMU0/1 Selection	DIP	28
S3	Boot Configuration Options	DIP	10
S4	RESET	Push button	29
S5	Pull Ups	DIP	14
SW1	Power On/Off	Toggle	29

3.5.1 S1, EMU0/1 Select Switch

S1 is a 2 position DIP switch providing 2 options in selecting the state of the EMU0 and EMU1 pins on the processor. A view of the switch is shown in the figure below. The selection options with this switch are in the table below.




Table 30: S1, EMU0/1 Select

State at Reset EMU0 EMU1		Function	TAP Configuration
L	L	Emulation Debug ARM JTAG Enabled (20 pin JTAG connector)	14 bit = (Bypass(6) + ARM9(4) + Bypass(4))
L	H	Not Defined	
H	L	Not Defined	
H	H	TI Emulation Debug * ICE PICK Mode	6 bit = ICE PICK

* is the factory shipped configuration

3.5.2 S3, Processor Configuration/Boot Load Options

S3 is a 10 position DIP switch providing 9 options in selecting the processor configuration and boot load modes. The connections for this switch are shown on page 10 of the schematics in appendix A. A view of the switch is shown in the figure below. The selection options with this switch are in the table below.




Table 31: S3, Processor Configuration/Boot Load Options

Position	Name	Function
1	COUT0	0 0 = Boot from ROM (NAND) *0 1 = Boot from AEM IF
2	COUT1	1 0 = Boot from ROM (HPI) 1 1 = Boot from ROM (UART)
3	COUT2	Selects AEMIF CS2 Bus width: 0=8 bit *, 1=16 bit
4	COUT3	Always Low
5	YOUT4	AEAW4
6	YOUT3	AEAW3
7	YOUT2	AEAW2
8	YOUT1	AEAW1
9	YOUT0	AEAW0
10		Composite Video Format

AEAW4:0 configure address pins required to boot. See the tables in the device data sheet for more information. For the DM357 all address active are selected.

3.5.3 S4, RESET

Switch S4 is a push button rest switch that will RESET the processor. This switch is in parallel with J6. The connections for this switch are shown on page 29 of the schematics in appendix A.

3.5.4 S5, User CPLD Option Switch

Switch S5 is a 2 position DIP switch that allows the user to select options on the PIN74 and PIN75 pins of the CPLD, U14. This switch is not used on the DM357 as shipped from the factory. This switch appears on page 14 of the schematics. The diagram below shows which position is associated with each signal.

3.5.5 SW1, Power On/Off

Switch S1 is a toggle switch that provides power to the EVM. The connections for this switch are shown on page 29 of the schematics in appendix A.

3.6 Jumper Block, JP1

The DM357 EVM has 6 position jumper that is not populated. This connector is used for test points on the CPLD internal operations during CPLD debug. The layout of the jumper block is shown below.




Figure 3-20, Jumper Block, JP1

The signals on each pin are shown in the table below.

Table 32: Jumper Block, JP1

Pin #	Signal	Pin #	Signal
1	U14, PIN92	2	U14, PIN95
3	U14, PIN91	4	U14, PIN96
5	U14, PIN90	6	U14, PIN97
7	U14, PIN89	8	U14, PIN98
9	U14, PIN88	10	U14, PIN99
11	U14, PIN87	12	U14, PIN100

3.8 Test Points

The EVM has 72 test points. All test points appear on the top of the board. The following figure identifies the position of each test point. the next table list each test point and the signal appearing on that test point.




Table 33: DM357 EVM Test Points


TP #	Signal	Page	TP #	Signal	Page
TP1	GND	29	TP37	U27, P4, PWRGD, VCC_5V	30
TP2	GND	29	TP38	GND	4
TP3	GND	29	TP39	U28A,T10, DDR_VDDDLL, 1.8V	4
TP4	U4, P24, P1.3/TA2	24	TP40	VCC_1.8V	4
TP5	VCC_5V	29	TP41	CORE_VDD	9
TP6	GND	4	TP42	U28D, M12, CPU_CORE_VDD	9
TP7	U28A, R8, RSV7	4	TP43	CORE_VDD	30
TP8	U28E, M2, PLLVDD18, VCC_1.8V	8	TP44	CORE_SUPPLY	30
TP9	GND	8	TP45	GND	4
TP10	U28E, L3, RSV6	8	TP46	U28H, H17, USB_VDDA1P8, VCC_1.8V	7
TP11	U28D, T5, CPU_VCC_1.8V, VCC_1.8V	9	TP47	VCC_1.8V	7
TP12	U38, P4, PWRGD, VCC_5V	30	TP48	VCC_3.3V	7
TP13	U44, P1, <u>RESET</u>	29	TP49	U28H, J19, USB_VDDA3P3.1, VCC_3.3V	7
TP14	+3.3V	29	TP50	U28G, P18, DAC_IOUT_B	5
TP15	U19, P6, PH1	29	TP51	U28G, R19, DAC_IOUT_C	5
TP16	U19, P4, PWRGD, 3V3_PWR_OK	34	TP52	U28G, T19, RSV45	5
TP17	GND	4	TP53	U28G, R18, VDDA_1P8V, VCC_1.8V	5
TP18	U28E, M3, RSV24, CORE_VDD	8	TP54	VCC_1.8V	5
TP19	VCC_1.8V	8	TP55	U28G, P16, VDDA_1P1V, CORE_VDD	5
TP20	CORE_VDD	8	TP56	U51,Pin 36, AVID/GPIO	20
TP21	VCC_1.8V	9	TP57	U51,Pin 37, GLCO/12CA	20
TP22	U28D, E13, CPU_VCC_3.3V, VCC_3.3V	9	TP58	U58,PIN 64,MDINT	22
TP23	U14, Pin 49, B1.PIN49	14	TP59	J10, Pin 4, USB_ID	17
TP24	U14, Pin 29, B1.PIN29	14	TP60	J10, Pin 1, USB_VBUS	17
TP25	CORE_VDDMX	30	TP61	CORE_VDD	5
TP26	VCC_1.8V	30	TP62	U51,Pin 30, INTREQ	20
TP27	GND	29	TP63	U52, A8, MPF2	22
TP28	VCC_3.3V	29	TP64	U52, A9,MPF3	22
TP29	U27, P6, PH1	30	TP65	U52, J8, GPIO2	22
TP30	CORE_VDDMX	9	TP66	U28I, C15, PWM0/GIO45, VCC_1.8V	5
TP31	U28DM K11, CPU_CORE_VDDMX	9	TP67	VIN, U54,PIN 3	5
TP32	VCC_3.3V	9	TP68	GND	29
TP33	U45, P1, <u>RESET</u>	29	TP69	U52, J9, GPIO1	22
TP34	U46, P1, <u>RESET</u>	29	TP70	GND	29
TP35	U38, P6, PH1	30	TP71	U68, Pin 4, USB.DRVVBUSz	17
TP36	VCC_1.8V	30	TP72	U68, Pin 5, USB.OVER_CURRENT	17

Appendix A


Schematics


This appendix contains the schematics for the DM357 EVM.

NOTES, UNLESS OTHERWISE SPECIFIED:		5		4		3		2		1											
		REV				DESCRIPTION				DATE APPROVED											
		A		Initial schematic ready for layout - Alpha Release						10/15/08											
6. BOARD PROPERTIES																					
A. ROUTE TO WITHIN 10% OF MANHATTAN DISTANCE General layers 50 +/ - 5 OIM MATCHED IMPEDANCE B1. General layer 50 ohm different. B2. Layer 50 ohm C. OUTER LAYERS 0.5 OZ CU / W 0.5 OZ AU PLATING D. INNER LAYERS 0.02 CU E. MINIMUM TRACE WIDTH SPACING 4 MILS F. MINIMUM VIA SIZE 10/1.9 MIL G. STACKUP H. STACKUP																					
7. GROUND PLANE ROUTING																					
1. TOP - SIGNAL ROUTING 2. GND PLANE ROUTING 3. VCC/GND PLANE 13.3V SIGNAL ROUTING 4. INNER 1 & 2 LAYER SIGNAL ROUTING 5. INNER 2 & 3 LAYER SIGNAL ROUTING 6. GND PLANE SIGNAL ROUTING 7. BOTTOM - SIGNAL ROUTING																					
8. VCC/GND PLANE ROUTING																					
A. ALL 0.1UF AND 0.01UF CAPACITORS ARE DECOUPLING CAPS UNLESS OTHERWISE NOTED, THEY ARE SHOWN ON THE PAGE WITH THE INTEGRATED CIRCUITS THEY SHOULD BE PLACED NEAR.																					
9. OBSERVE THE FOLLOWING LAYOUT NOTES:																					
A. ROUTE TO WITHIN 10% OF MANHATTAN DISTANCE General layers 50 +/ - 5 OIM MATCHED IMPEDANCE B1. General layer 50 ohm different. B2. Layer 50 ohm C. OUTER LAYERS 0.5 OZ CU / W 0.5 OZ AU PLATING D. INNER LAYERS 0.02 CU E. MINIMUM TRACE WIDTH SPACING 4 MILS F. MINIMUM VIA SIZE 10/1.9 MIL G. STACKUP H. STACKUP																					
10. TOP - SIGNAL ROUTING																					
1. TOP - SIGNAL ROUTING 2. GND PLANE ROUTING 3. VCC/GND PLANE 13.3V SIGNAL ROUTING 4. INNER 1 & 2 LAYER SIGNAL ROUTING 5. INNER 2 & 3 LAYER SIGNAL ROUTING 6. GND PLANE SIGNAL ROUTING 7. BOTTOM - SIGNAL ROUTING																					
11. Schematic Contents																					
0.1 DM357 EVM TITLE SHEET 0.2 DM357 EVM BLOCK DIAGRAM 0.3 DM357 ENIF INTERFACE 0.4 DM357 DDR INTERFACE 0.5 DM357 VIDEO INTERFACE 0.6 DM357 I/O INTERFACE 0.7 DM357 USB & SD/MMC/MS CONTROLER 0.8 DM357 EMULATION & CLOCKS 0.9 DM357 POWER PINS 10 DM357 CONFIGURATION CONTROL/BOOT OPTIONS																					
12. Component Legend																					
06.50 12C IC 06.1B A17C13 08.5D TPS5146 08.5B 10 EXPANDER 0 (LED) 08.49 10 EXPANDER 1 (HLL/USER_S9) 08.3A 10 EXPANDER 2 (USB/CD_RSSET) 08.23 M59410																					
13. Address Table																					
6 22 22 22 20 20 23 23 23 23 24 24 25 25 26 26 27 27 28 28 29 29 30 30 31 31 32 32 33 33 34 34 35 35 36 36 37 37 38 38 39 39 40 40 41 41 42 42 43 43 44 44 45 45 46 46 47 47 48 48 49 49 50 50 51 51 52 52 53 53 54 54 55 55 56 56 57 57 58 58 59 59 60 60 61 61 62 62 63 63 64 64 65 65 66 66 67 67 68 68 69 69 70 70 71 71 72 72 73 73 74 74 75 75 76 76 77 77 78 78 79 79 80 80 81 81 82 82 83 83 84 84 85 85 86 86 87 87 88 88 89 89 90 90 91 91 92 92 93 93 94 94 95 95 96 96 97 97 98 98 99 99 100 100 101 101 102 102 103 103 104 104 105 105 106 106 107 107 108 108 109 109 110 110 111 111 112 112 113 113 114 114 115 115 116 116 117 117 118 118 119 119 120 120 121 121 122 122 123 123 124 124 125 125 126 126 127 127 128 128 129 129 130 130 131 131 132 132 133 133 134 134 135 135 136 136 137 137 138 138 139 139 140 140 141 141 142 142 143 143 144 144 145 145 146 146 147 147 148 148 149 149 150 150 151 151 152 152 153 153 154 154 155 155 156 156 157 157 158 158 159 159 160 160 161 161 162 162 163 163 164 164 165 165 166 166 167 167 168 168 169 169 170 170 171 171 172 172 173 173 174 174 175 175 176 176 177 177 178 178 179 179 180 180 181 181 182 182 183 183 184 184 185 185 186 186 187 187 188 188 189 189 190 190 191 191 192 192 193 193 194 194 195 195 196 196 197 197 198 198 199 199 200 200 201 201 202 202 203 203 204 204 205 205 206 206 207 207 208 208 209 209 210 210 211 211 212 212 213 213 214 214 215 215 216 216 217 217 218 218 219 219 220 220 221 221 222 222 223 223 224 224 225 225 226 226 227 227 228 228 229 229 230 230 231 231 232 232 233 233 234 234 235 235 236 236 237 237 238 238 239 239 240 240 241 241 242 242 243 243 244 244 245 245 246 246 247 247 248 248 249 249 250 250 251 251 252 252 253 253 254 254 255 255 256 256 257 257 258 258 259 259 260 260 261 261 262 262 263 263 264 264 265 265 266 266 267 267 268 268 269 269 270 270 271 271 272 272 273 273 274 274 275 275 276 276 277 277 278 278 279 279 280 280 281 281 282 282 283 283 284 284 285 285 286 286 287 287 288 288 289 289 290 290 291 291 292 292 293 293 294 294 295 295 296 296 297 297 298 298 299 299 300 300 301 301 302 302 303 303 304 304 305 305 306 306 307 307 308 308 309 309 310 310 311 311 312 312 313 313 314 314 315 315 316 316 317 317 318 318 319 319 320 320 321 321 322 322 323 323 324 324 325 325 326 326 327 327 328 328 329 329 330 330 331 331 332 332 333 333 334 334 335 335 336 336 337 337 338 338 339 339 340 340 341 341 342 342 343 343 344 344 345 345 346 346 347 347 348 348 349 349 350 350 351 351 352 352 353 353 354 354 355 355 356 356 357 357 358 358 359 359 360 360 361 361 362 362 363 363 364 364 365 365 366 366 367 367 368 368 369 369 370 370 371 371 372 372 373 373 374 374 375 375 376 376 377 377 378 378 379 379 380 380 381 381 382 382 383 383 384 384 385 385 386 386 387 387 388 388 389 389 390 390 391 391 392 392 393 393 394 394 395 395 396 396 397 397 398 398 399 399 400 400 401 401 402 402 403 403 404 404 405 405 406 406 407 407 408 408 409 409 410 410 411 411 412 412 413 413 414 414 415 415 416 416 417 417 418 418 419 419 420 420 421 421 422 422 423 423 424 424 425 425 426 426 427 427 428 428 429 429 430 430 431 431 432 432 433 433 434 434 435 435 436 436 437 437 438 438 439 439 440 440 441 441 442 442 443 443 444 444 445 445 446 446 447 447 448 448 449 449 450 450 451 451 452 452 453 453 454 454 455 455 456 456 457 457 458 458 459 459 460 460 461 461 462 462 463 463 464 464 465 465 466 466 467 467 468 468 469 469 470 470 471 471 472 472 473 473 474 474 475 475 476 476 477 477 478 478 479 479 480 480 481 481 482 482 483 483 484 484 485 485 486 486 487 487 488 488 489 489 490 490 491 491 492 492 493 493 494 494 495 495 496 496 497 497 498 498 499 499 500 500 501 501 502 502 503 503 504 504 505 505 506 506 507 507 508 508 509 509 510 510 511 511 512 512 513 513 514 514 515 515 516 516 517 517 518 518 519 519 520 520 521 521 522 522 523 523 524 524 525 525 526 526 527 527 528 528 529 529 530 530 531 531 532 532 533 533 534 534 535 535 536 536 537 537 538 538 539 539 540 540 541 541 542 542 543 543 544 544 545 545 546 546 547 547 548 548 549 549 550 550 551 551 552 552 553 553 554 554 555 555 556 556 557 557 558 558 559 559 560 560 561 561 562 562 563 563 564 564 565 565 566 566 567 567 568 568 569 569 570 570 571 571 572 572 573 573 574 574 575 575 576 576 577 577 578 578 579 579 580 580 581 581 582 582 583 583 584 584 585 585 586 586 587 587 588 588 589 589 590 590 591 591 592 592 593 593 594 594 595 595 596 596 597 597 598 598 599 599 600 600 601 601 602 602 603 603 604 604 605 605 606 606 607 607 608 608 609 609 610 610 611 611 612 612 613 613 614 614 615 615 616 616 617 617 618 618 619 619 620 620 621 621 622 622 623 623 624 624 625 625 626 626 627 627 628 628 629 629 630 630 631 631 632 632 633 633 634 634 635 635 636 636 637 637 638 638 639 639 640 640 641 641 642 642 643 643 644 644 645 645 646 646 647 647 648 648 649 649 650 650 651 651 652 652 653 653 654 654 655 655 656 656 657 657 658 658 659 659 660 660 661 661 662 662 663 663 664 664 665 665 666 666 667 667 668 668 669 669 670 670 671 671 672 672 673 673 674 674 675 675 676 676 677 677 678 678 679 679 680 680 681 681 682 682 683 683 684 684 685 685 686 686 687 687 688 688 689 689 690 690 691 691 692 692 693 693 694 694 695 695 696 696 697 697 698 698 699 699 700 700 701 701 702 702 703 703 704 704 705 705 706 706 707 707 708 708 709 709 710 710 711 711 712 712 713 713 714 714 715 715 716 716 717 717 718 718 719 719 720 720 721 721 722 722 723 723 724 724 725 725 726 726 727 727 728 728 729 729 730 730 731 731 732 732 733 733 734 734 735 735 736 736 737 737 738 738 739 739 740 740 741 741 742 742 743 743 744 744 745 745 746 746 747 747 748 748 749 749 750 750 751 751 752 752 753 753 754 754 755 755 756 756 757 757 758 758 759 759 760 760 761 761 762 762 763 763 764 764 765 765 766 766 767 767 768 768 769 769 770 770 771 771 772 772 773 773 774 774 775 775 776 776 777 777 778 778 779 779 780 780 781 781 782 782 783 783 784 784 785 785 786 786 787 787 788 788 789 789 790 790 791 791 792 792 793 793 794 794 795 795 796 796 797 797 798 798 799 799 800 800 801 801 802 802 803 803 804 804 805 805 806 806 807 807 808 808 809 809 810 810 811 811 812 812 813 813 814 814 815 815 816 816 817 817 818 818 819 819 820 820 821 821 822 822 823 823 824 824 825 825 826 826 827 827 828 828 829 829 830 830 831 831 832 832 833 833 834 834 835 835 836 836 837 837 838 838 839 839 840 840 841 841 842 842 843 843 844 844 845 845 846 846 847 847 848 848 849 849 850 850 851 851 852 852 853 853 854 854 855 855 856 856 857 857 858 858 859 859 860 860 861 861 862 862 863 863 864 864 865 865 866 866 867 867 868 868 869 869 870 870 871 871 872 872 873 873 874 874 875 875 876 876 877 877 878 878 879 879 880 880 881 881 882 882 883 883 884 884 885 885 886 886 887 887 888 888 889 889 890 890 891 891 892 892 893 893 894 894 895 895 896 896 897 897 898 898 899 899 900 900 901 901 902 902 903 903 904 904 905 905 906 906 907 907 908 908 909 909 910 910 911 911 912 912 913 913 914 914 915 915 916 916 917 917 918 918 919 919 920 920 921 921 922 922 923 923 9																					




Spectrum Digital, Inc







Spectrum Digital, Inc





DM357 EVM Technical Reference






DM357 EVM Technical Reference






A-10


DM357 EVM Technical Reference








A-12

DM357 EVM Technical Reference












SPECTRUM DIGITAL INCORPORATED	
Title:	TMS320DM357 EVALUATION MODULE
Page Contents:	SD/MMC CONNECTOR
Size: B	DWG NO 511452-0001
Date: Monday November 03, 2008	Sheet 1 of 30
	Revision: A






SPECTRUM DIGITAL INCORPORATED	
A	
Type:	TMS320DM357 EVALUATION MODULE
Page Contents:	USB 2.0 INTERFACE
Size B	Dwg No 5114520001
Revision:	A
Date:	Monday, November 03, 2008
Sheet	17 of 30




Place terminations
close to PHY source





A-20


DM357 EVM Technical Reference




Spectrum Digital, Inc










SPECTRUM DIGITAL INCORPORATED	
Title:	TMS320DM357 EVALUATION MODULE
Page Contents:	SPDIF OUTPUTS & USER LEDS
Size: B	Dwg No: 511452-0001
Date: Monday November 03, 2008	Revision: A
Street: 23 o f	30






SPECTRUM DIGITAL INCORPORATED	
Title:	TMS320DM357 EVALUATION MODULE
Page Contents:	EMIF EXPANSION CONNECTOR
Size: B	DWG NO 511452-0001 Revision: A
Date: Monday November 03, 2008	Street 25 o 1 30 1








» EMULATOR_RSIn 29

SPECTRUM DIGITAL INCORPORATED	
TMS20D457 EVALUATION MODULE	
Page Contents:	DAVINCI EVALUATION HEADER
Size B	DWG NO. 511452-0001
Date: Monday, November 03, 2008	Revision: A
Sheet 28 of 30	Sheet 1 of 1



SPECTRUM DIGITAL INCORPORATED

TMS320DM357 EVALUATION MODULE

Title: TMS320DM357 EVALUATION MODULE

Page Contents: POWER SUPPLY (1.3V) / SYSTEM RESET LOGIC


Size: B

Date: Monday, November 03, 2008

Dwg No: 511452-0001

Revision: A


Sheet: 29 of 30



Appendix B


Mechanical Information

This appendix contains the mechanical information about the DM357 EVM produced by Spectrum Digital.



Spectrum Digital, Inc

Spectrum Digital, Inc



Printed in U.S.A., December 2008
511455-0001 Rev A